



## Directions for Ford Raptor Rear Drill-less Installation

### Supplied Hardware:

6- #8 x 1 1/4" Stainless Steel Black Oxide (SSBO) screws; 6- #10 (SSBO) washers.

Step 1: Remove factory screws at points A,B, and C.

Step 2: Bend the mud flap to match the curve of the fender well.

Step 3: Align the flap with the factory holes and the holes in the flap, secure with the screws with washers that are included in the bolt pack. Leave slightly loose.

Step 4: Ensure the flap is plumb to the outside of the tire and tighten all the screws.

**NOTE:** Recheck monthly and tighten if necessary.

IF YOU HAVE ANY QUESTIONS OR CONCERNS PLEASE GIVE US A CALL AT 541-245-9148.



FR12 21 Raptor, FR14 21 Raptor